



8: BODY / SUB - ASSEMBLY 'A'

NOTE: Paint body, hood and optional hood scoop (pat No. 92 if used) color of choice before assembly. Paint ROCKER PANELS (Shaded Areas) - Black.





9: BODY / SUB - ASSEMBLY 'B'




11: DECAL APPLICATION

- Cut the desired decal from the decal sheet.
- Dip decal in warm water to loosen decal from backing paper.
- Place decal in position and slide off backing paper.
- Remove air bubbles by wiping gently with damp cloth.




10: BODY / FINAL ASSEMBLY




8: BODY / SUB - ASSEMBLY 'A'

NOTE: Paint body, hood and optional hood scoop (pat No. 92 if used) color of choice before assembly. Paint ROCKER PANELS (Shaded Areas) - Black.






9: BODY / SUB - ASSEMBLY 'B'



11: DECAL APPLICATION

- Cut the desired decal from the decal sheet.
- Dip decal in warm water to loosen decal from backing paper.
- Place decal in position and slide off backing paper.
- Remove air bubbles by wiping gently with damp cloth.



Stock No. 6804

Form No. 099 - 6804

PRO-STREET

Unitary and righteous mechanicals, of se, should be housed in an equally ary and righteous body, and the slick takes well to the latest trick paints and the eye" graphics. Neons, pastels and deep "glow in the sun" metallics and s bring out the muscular shapes of the . If you are looking for a "take no mers" ultimate pro-street meanie, the 'AR muscle car Pro-Street GTX is hard at in many more ways than one.

just like the real thing in table-top size.

HOBBY KNIFE

A sharp hobby knife nrove parts from the Some parts may r to have an extra on them, these should moved.




TWEEZERS

ezers are handy for ng very small parts g assembly or ng.



CEMENT

recommnd the use liquid polystyrene t. Apply with a fine or toothpick. Use at sparingly or a y job will result.



ADVANCED MODELER


Small gaps that may occur between parts and to blend rs. This should be done only after the first, or tr," coat of paint is applied. n painting a two-tone body, the lightest color should t first. Use frosted, or "magic," tape to mask off the u do not want painted. After the second color is dry uch, the tape can be removed. Use a very fine brush h up edges if necessary. If decals are to be added, do re adding any gloss coat. A gloss coat will help ven : edges between the two colors as well as set the

ake great pride in providing the finest model kits lable, giving strong attention to detail and smanship. Should you have any difficulty with mbly or missing parts, please call the appropriate ber listed below between the hours of 8:00 am to pm central time, Monday through Friday.

IOWA (toll free) 1-800-942-4618
 elsewhere in the U.S.A. (toll free) 1-800-553-4886
 outside of the United States call 1-319-875-2000


TH
 Hig
 Dye
 PRINT

1: ENGINE / SUB-ASSEMBLY




2: ENGINE / FINAL ASSEMBLY

NOTE: Do not use AIR FILTER or VELOCITY STACKS if HOOD SCOOP is used; Ref assembly 8.




3: INTERIOR ASSEMBLY


NOTE: Radio knobs must be removed to use GAUGE CLUSTER.




4: CHASSIS / SUB-ASSEMBLY 'A'



5: CHASSIS / SUB-ASSEMBLY 'B'



6: CHASSIS / SUB-ASSEMBLY 'C'



7: CHASSIS / FINAL ASSEMBLY

