
INSTRUCTION MANUAL



GAT-X105 STRIKE FIGHTER

强襲戰士





《組裝時的注意》

- 組裝前請詳細閱讀説明書。
- ●請將零件按編號整齊組裝,組裝後把邊角料丢弃。
- 零配件當中有帶尖鋭或刺手的, 在組裝時請小心。
- 建議在塗裝粘貼時使用安全的"水性塗料"。

NOTICE WHILE ASSEMBLING

- Please read the instruction carefully before assembly.
- Please assemble the parts as per the serial numbers and discard the leftover material after assembly.
- While assembling, please pay attention that some of the parts may be sharp-pointed or aciculate.
- Please use the safe "aqueous coating" while painting.






















結合數值旋轉 base on the mark n




パーツリスト


Aパーツ (スチロール樹脂: PS)




Bパーツ (スチロール樹脂:PS)




Cパーツ (×2) (スチロール樹脂: PS)



Dパーツ (×2)












<mark>Gパーツ</mark> (スチロール樹脂: PS)





(ABS樹脂: ABS)





(ABS樹脂: ABS)































電池金具パーツ

電池金具·A 電池金具·B







発光ダイオード(YELLOW)













- ●ビスTP2×6…1
- ●マーキングシール…1

※発光ダイオード(YELLOW)を点灯させたい方はボタン電池(CR1220 (1個)・別売り)をご使用ください。

适用年龄:十五岁以上



CHOKING HAZARD-Small parts. Not for children under 15 years.













▲警告


- 不适合六岁以下儿童使用
- 含有小零件,请勿吞食,以免 造成窒息危险;
- 内有尖端物小心使用请勿刺 人,以免造成伤害;
- 请在成人指导下正确使用;































Mo


CO


2_{x2}




2 ×2


NO









2


















(先に取り付ける) **S値**

Jø

ダイカストB







5(4)





C (×2)




D (×2)













SO













































点灯テスト


ON ※点灯させない時は、電池をはずします。

- 点灯しない場合
 1.電池の+-(ブラスマイナス)は合っていますか。
 2.電池は古くありませんか。
 3.発光ダイオードの向きは合っていますか。
 4.接点が離れていませんか。
 接点が離れている場合、接点がつくように、発光ダイオードの足や電池金具を微調整して点灯するようにします。




ボタン電池の交換方法










8

GO


SO

G9 · G0





G



Α

S

GO

・組立8で使用するパーツ






S


E@


9


AØ

A®





























GAT-X105 STRIKE FIGHTER